


Low E Cleaning and Maintenance

In order to maintain clean glass surfaces, cleaning must be performed on a regular basis.

The following is a basic guide for cleaning products within the Glass range.

- 1. Rinse with water to remove loose dirt and particles**
- 2. Wash with warm soapy water or vinegar based commercial solvent for stubborn stains.**
- 3. Cleaning solution should be wiped onto the glass surface using a circular motion and applying light to moderate pressure.**
- 4. Rinse the glass surface generously with warm water to remove all traces of the cleaning solution.**
- 5. Using a Squeegee or clean lint free dry cloth, remove the water from the glass surface.**
- 6. Repeat the above steps if necessary.**
- 7. These instructions are issued as a general guide only.**

Note: solvent manufacturer's directions and warnings must be followed at all times and care should be taken to avoid contact with glazing sealants or other materials that may be affected by such.

A yellow rectangular box with a black border containing text. An arrow points from the top-left corner of the box towards the note above.

IF GLASS IS MARKED, TRY METHO THEN IMMEDIATELY RINSED WITH WATER IF THIS DOES NOT WORK TRY A TEASPOON (5ml) OF 32% POOL ACID INTO 150mm OF WATER, WIPE ON AND IMMEDIATELY AFTER RINSE WITH WATER